

SPRITZER SHUT-DOWN PROCEDURES



Read through all the steps before starting procedure. Please refer to the appropriate MSDS for proper safe handling including the use of safety glasses, protective gloves, and respirator protection where needed.

For any reason if you do not understand, or are uncertain of any or all procedures and instructions given to you by Foam Supplies, Inc. and its representatives, please contact our Technical Service Dept. before attempting procedures. We will be happy to assist.

PROTECTIVE EYEWEAR AND GLOVES REQUIRED!

- 1. Engage trigger safety on gun.
- 2. Remove mix tube.
- 3. Close both ISO (A) and POLYOL (B) ball-valves at gun whip.
- 4. Clean gun face of chemical and foam.
- 5. Lubricate gun face with petroleum jelly or lithium-based grease.
- 6. Close chemical and Nitrogen (N₂) ball-valves on cylinders.
- 7. Turn Nitrogen (N₂) supply **OFF**.